

1151 South – Theater Presentation Guide

- At control panel on lectern, press “**ON**” to turn on projector.
- On wall switch behind lectern, press switch down to lower projection screen.
- Press the unlabeled “**BLUE**” button to turn on receiver.
- Volume for all sources should be adjusted with the DENON remote control.
- AV mute button on control panel drops video source and mutes audio. Press again to restore video and audio.

To display presentation PC:

1. Turn on PC located inside lectern (Power button is on the front.)
2. Turn PC/Laptop switch inside lectern to **PC** position.
3. Turn on monitor located on top of lectern.
4. Press “**PC**” on control panel to send PC display to projection screen.

To play DVD from Blu-ray DVD player:

1. Insert DVD into Blu-ray DVD player located inside lectern.
2. Press “**DVD**” on control panel to send Blu-ray video to projection screen.

To share personal laptop:

1. Connect VGA cable (not supplied) from laptop connector to control panel connector.
 2. Connect audio cable (not supplied) from headphone jack on laptop to audio jack on the control panel.
 3. Turn PC/Laptop switch inside lectern to **LAPTOP** position.
 4. Press “**LAP**” on control panel to send laptop display to projection screen.
- **Remember to log off or shut down presentation PC when finished.**
 - Press the unlabeled “**BLUE**” button on the control panel to turn off receiver.
 - At control panel on lectern, press “**OFF**” to turn shut down projector. (At this time, it is necessary to press ON, OFF to complete shutdown.)
 - On wall switch behind lectern, press switch up to raise projection screen.